

# User manual




## Universal moisture meter for biomass **humimeter BL2**











Version 1.2\_en



© Schaller GmbH  
2014

## Design BL2 hammer (art.no. 12520)



## Measuring procedure BL2 hammer

1. For a correct measurement please ensure that the device has the same temperature than the wood ( $\pm 3^{\circ}\text{C}$ ). For that reason, let your humimeter BL2 hammer adjust to the surrounding temperature of the material for at least half an hour before measuring.
2. Switch on the device: Press the  key for **three seconds**.
3. Choose a part of the wood, **WITHOUT bark, branches, pitch pockets or cracks** and drive the ram electrode in the right angle to the grain into the wood. Hold the top of the electrode with one hand, take the handhold with the other hand and push down the handhold with active force. Drive the nails about 2 cm deep into the wood.  
**Attention: Risk of injury!!!**
4. Plug in the sensor cable into the socket of the BL2. Take care of the correct position and fix it with the knurled nut.
5. Change the calibration curve: Press one time the  key and then the  or  key. The name of the calibration curve can be seen at the head of the display.
6. **Now the display shows the water content.** Left hand the temperature is displayed.
7. To save the results in the save menu press the  ( button). The storage was successful when the number in front of the symbol  increased. To reach the store menu please press () until the  appears.
8. To name the saved results press the  button.
9. Push out the ram electrode of the wood with caution.



## Informations for measurement with BL2 hammer

- With the standard nails the wettest part over the whole measuring depth will be measured. If you need the water content in a defined measuring depth, you should use the isolated green nails (article number 11426), because they are only measuring at the points.
- Important: You have to remove the bark before you can start to measure.
- The measuring depth should be a quarter of the wood diameter. In the worst case you have to cut away a part of the diameter.
- Statistically, the spot that shows best the average moisture of the wood is at about 20% of the total wood length.
- Take a few logs on different positions of each piece of wood you intend to measure, and the humimeter BL2 will calculate automatically the average value of the series.
- The measure value which is shown at the display of your humimeter BL2, represents the “water content” of the wood. So there is no conversion from the “wood moisture” into “water content” for use. It is also possible to change the value into “wood moisture”. If you need this, contact [support@humimeter.com](mailto:support@humimeter.com)
- Definition water content:

The water content is declared as the amount of water in a wood, which stands in relationship to the whole weight of the wood. For example: You have 1kg Wood with 40% water content; the wood consist of 0,4kg water and 0,6kg wood.

- Definition wood moisture:

The wood moisture is declared as the amount of water in a wood, which stands in relationship to the weight of the dried wood. The same example: You have 0,6kg Wood with 0,4kg water; the 0,6kg wood represents 100%, so the 0,4kg water will be 66,7% wood moisture.

## Sorts (calibration curves) BL2 hammer

Main Group	Sub groups							
<b>Beech</b>	Rubber							
<b>Oak</b>	Mahogany	Wenge						
<b>Alder</b>	Acacia	Alstonia	Birch	European chestnut	Horse chestnut	Cherry Tree	Walnut	Okan
<b>Ash</b>	Keruing							
<b>Spruce</b>								
<b>Pine</b>	Balsa	Yew Tree	Stone Pine					
<b>Larch</b>	Maple	Douglas Fir	Hemlock	Cotton Wood	Elm			
<b>Fir</b>	Ceiba	Linden						
<b>Willow</b>	Pear	Hickory	Olive wood	Ramin	Teak			
<b>Straw</b>	Only for use with the tip set for straw-bales (article no. 12521) max. compression density: 100 to 130kg/m <sup>3</sup>							
<b>Hay</b>	Only for use with the tip set for straw-bales (article no. 12521) max. compression density: 100 to 130kg/m <sup>3</sup>							
<b>Cellulose</b>	Only for use with the tip set for straw-bales (article no. 12521) max. compression density: 38 to 65kg/m <sup>3</sup>							
<b>Digit 1</b>	For special products							
<b>Empty 1</b>	For special calibration, realized by company Schaller GmbH							
<b>Test block</b>	Only for checking the calibration with the test block							

Declaration: The main group of wood is the wood sort, which is shown on the measurement display of your humimeter BL2. Do you want to measure wood, which is not in the list of the main group, you should search it at the sub groups in the table above. Then use the wood of the main group for the measuring. For example: If you want to measure “Cherry Tree”, you have to choose the “Alder” wood at you device.

### Valid measuring Range


Beech	32%
Oak	32%
Alder	40%
Ash	35%
Spruce	40%
Pine	35%
Larch	32%
Fir	37%
Willow	40%

If the measure value is grey, the standard valid measuring range is exceeded (limits see Table). In this case the accuracy will be decreasing.

A blinking measuring value shows you the upper end of the measuring range.













## Design BL2 wood chips probe (art. no. 12518)





## Measuring procedure BL2 wood chips probe

1. For a correct measurement please ensure that the device has the same temperature than the wood chips ( $\pm 3^{\circ}\text{C}$ ). For that reason, let your humimeter BL2 adjust to the surrounding temperature of the material for at least half an hour before measuring.
2. Switch on the device: Press the  key for **three seconds**.
3. Plug the probe of your BL2 wood chips probe **straight into the wood chips**. It is not allowed to load the measuring head incorrect or drop it down!
4. Plug in the sensor cable into the socket of the BL2. Take care of the correct position and fix it with the knurled nut.
5. Change the calibration curve: Press one time the  key and then the  or  key. The name of the calibration curve can be seen at the head of the display.
6. **Now the display shows the water content.** Left hand the temperature is displayed.
7. To save the results in the save menu press the  ( button). The storage was successful when the number in front of the symbol  increased. To reach the store menu please press () until the  appears.
8. To name the saved results press the  button.
9. Remove the BL2 probe straight with caution and clean the measuring head.  
**Risk of injury by measuring head!**  
**Keep away from children!**



## Calibration curves BL2 wood chips probe

Calibration curves	Declaration	Measuring range
Wood chips	Standard wood chips	10 - 50 %
Coarse chips	Coarse wood chips	10 - 50 %
Industrial chips	Industrial wood chips	10 - 50 %
Pellets	Pellets made of wood	11 - 20 %
Sawdust	Sawdust	14 - 50 %
Olive stones	Shredded olive stones	10 - 21 %
Digit 2	For special product	
Empty 2	Customer calibration made by Schaller GmbH	
Test block	<i>! Only for testing the BL2 with the test block !</i>	

- **Wood chips:** standard chips of wood (forest wood chips) according to standard EN 14961 class **P16**, **P31.5** and **P45**.
- **Coarse chips:** for coarse wood chips **P45** or **P31.5** but with **fewer fines**.
- **Industrial chips:** for industrial chips of wood **without barks and fines** (similar **P45** or **P63**)

### Definition of wood chips classes

The stated numbers refer to the particle size that goes through round gaps of the corresponding diametres (e.g. P16: 16 mm).

- **P16** minimum 75% of the bulk is between 3.15 and 16 mm
- **P31,5** minimum 75% of the bulk is between 8 and 31.5 mm
- **P45** minimum 75% of the bulk is between 8 and 45 mm
- **P63** minimum 75% of the bulk is between 8 and 63 mm

### Compression of wood chips

The humimeter BLL is calibrated for normally compressed wood chips. If the measured wood chips are compressed to a much lesser or greater extent, this will cause measuring imprecisions. Normally compressed wood chips are defined in norm EN 15103 (determination of the bulk density).



# Determination of the material reference moisture

The principle is a comparison measurement with the dehydration method according to EN 14774. Take the measured sample and weigh it. Dry it out in an oven and weigh it again.

$$\%F = \frac{M_n - M_t}{M_n} \times 100$$

$M_n$ : Mass with average moisture content

$M_t$ : Mass of the dried sample

%F: Calculated absolute moisture

## Pictures of different types of wood chips for determination of correct calibration curve

### Woodchips






## Coarse ch.



## Industr. WC



## Menu level overview



## Overview main menu

<i>Edit Logs</i>	<i>Options</i>
Manual Logs	Date / Time
Clear Logs	Log Time
<i>Print Logs</i>	Language
Last Log	Unlock
All Logs	°C / °F
Clear Logs	o Userlevel
<i>Send Logs</i>	BL On Time
Manual Logs	Auto Off Time
Clear Logs	Materialcalib.
<i>Options</i>	Password
<i>Status</i>	Reset

## Keypad symbols

### Measuring window:

- Rolling Menu
- Power ON / OFF
- Switch upper
- Switch lower
- Save
- Hold
- Watch the saved data
- Suppliers data can be added
- Rotate display

### Menu:

- Enter
- Switch upper
- Switch lower
- Exit
- Enter numbers
- Enter letters
- Next or right
- Left
- Yes
- No
- Shift
- OK

## Changing batteries

Please find enclosed the manual for changing of batteries:

- 1.) At first remove the rubber protective housing. For that, hold the rubber housing at the upper side and pull it over. If your BL2 is provided with an optional USB port, you have to remove the protection cap before.
- 2.) Press with your finger onto the arrow of the battery cap und pull it back.
- 3.) Remove the empty batteries.
- 4.) Put four new batteries in the device. Make sure that the position of the battery poles is correct.
- 5.) Press down the batteries and close the cap.












If the battery symbol appears in the measuring window resp. if a critical charge of battery is shown in the status, the batteries have to be changed IMMEDIATELY. If you do not use your humimeter device for a longer period, remove the batteries. For eventual resulting damages we cannot provide any warranty.










## Running the instrument

- Switch on: Press the  key for three seconds
- Set the clock: Press three times the  key -> Options -> Date/Time
- Save measuring value: Save the measuring value by pressing the button below the  symbol. The storage was successful when the number in front of the symbol  increased. To name the saved results press the  button.
- Hold measuring value: At first activate the function in the menu Options -> Datalog time by choosing "Hold". Then press the left key until  appears. Press the  key. The measuring value remains on the display until another button is pressed.
- Display lighting: Press the  key; Backlight will turn off automatically after 30 seconds. Backlight will be activated by pressing any key.
- Power off: Press the  key for five seconds; the device will be switched off when you leave the key. The device also switches off automatically when no key is pressed for four minutes.
- Measuring range limit: If the measuring value is blinking, the valid measuring range is exceeded. In this case the accuracy will be decreasing.





## List of calibration curves

Pressing the  or  key in the measuring for at least three seconds and a list with all available sorts will appear. Select your sort by pressing  or  and confirm it with the  key. The measurement will continue automatically.



## Activation of the “super user” function

Two times  - *Options* – Unlock


Enter the 4-digit password by using the  button (standard is the 4-digit serial number) and confirm by pressing the  button.

## Changing the Userlevel



### Changing from advanced user to single user:


Make sure that you have activated the “super user” functions according to the instructions above. Afterwards change to the menu and choose „Options“.

In the submenu please select „o Userlevel“ (two times  - *Options* – o *Userlevel*)

Confirm by pressing the  button. Now the single user is activated.

### Changing from single user to advanced user:

Keep both the buttons  and  pressed directly after switching on the device. Your humimeter automatically starts the main menu. Activate the the “super user” functions according to the instructions above.

Navigate to “*Options* – o *Userlevel*” and confirm by pressing the  button.

## Device maintenance instructions

To provide a long life of your device please does not expose it to strong mechanical loads or heat e.g. dropping it or direct sunlight exposure. Clean your device using a dry cloth. Any kind of wet cleaning damages the device.

It is not allowed to load the measuring head incorrect (stress, bending), otherwise it can be broken. Plug and remove the insertion probe of your BL2 straight into the wood chips.

The instrument is not rainproof. Keep it in dry areas. When the device isn't used for a longer period (2 months) or when the batteries are empty, they should be removed to prevent a leakage of the battery acid.



## Transfer saved data to the PC




### ***(Only possible with humimeter USB interface module)***

To send your saved logs to the PC, connect the humimeter device to your PC using the USB cable that was delivered with your device. Carefully loose the protection cap on your humimeter and plug in the USB mini B connector. The bigger connector has to be connected to a USB slot on your PC.

Start the LogMemorizer software on your PC and switch on your humimeter BL2.

The data transfer can be started on your humimeter or on the software.

#### Starting the data transfer on the humimeter:

Press the  key until you reach the menu (see image on the right). Then choose „Send Logs“ and confirm by pressing the  key. Now choose „Manual Logs“ and confirm with  again. All saved logs will be sent to your PC.





#### Starting the data transfer on your PC:

Press the button „remote control“ in the LogMemorizer software. A drop-down menu with several options opens (see image below).

For transferring the data you can select „Import last manual log“ (the last saved measuring series is transferred) or „Import all manual logs“ (all saved logs are transferred).

If you click on one of these menu items, the transfer starts immediately.


For the basic adjustments of the software please look through the instructions on the LogMemorizer CD.





## Print saved data


***(Only possible with humimeter USB interface module in combination with Schaller thermo printer)***

To print your saved data, connect the device to the printer using the printer cable that was delivered with your device. Carefully loose the protection cap on the humimeter BL2. At first plug in the side of the connector with the close plastic casing at the humimeter BL2. Then switch on the device.


Not till then the other side of the cable has to be plugged in at the printer. Switch on the printer by pressing . Now the green LED is blinking. If it does not blink, please change the batteries and try again.

Press the  button at your humimeter until you reach the menu (see image on the right). Choose „Print Logs“ and confirm by pressing .

Now you can select if you want to print the last saved measuring series or all saved measuring series (logs).

Confirm by pressing  again. The selected logs are printed out now.

To save paper, please think of clearing the data storage regularly.



## Technical data BL2 (Art. Nr. 12109)

<b>Operation temperature</b>	0 °C to +50 °C
<b>Storage temperature</b>	-20 °C to +60 °C
<b>Temperature compensation</b>	Automatically
<b>Data logger</b>	approximately 10.000 values
<b>Menu languages</b>	German, English, French, Italian, Spanish, Russian
<b>Power supply</b>	4 pcs. 1.5 Volt AA <u>Alkaline</u> batteries (900 measurements)
<b>Auto Switch off</b>	After approx. four minutes
<b>Current consumption</b>	60mA (with light)
<b>Display</b>	128 x 64 matrix display, lighted
<b>Dimension</b>	150 x 75 x 30 mm
<b>Weight</b>	270 g (with batteries)
<b>Protection class</b>	IP 40
<b>Scope of supply</b>	humimeter BL2, 4 x 1,5Volt AA Alkaline batteries, rubber protective housing
<b>Optionen</b>	wooden case for BL2, test block, humimeter USB-data interface modul, portable thermo-printer

## Exemption from liability

For miss-readings and wrong measurements and of this resulting damage we refuse any liability. This is a device for quick determination of moisture. The moisture depends on multiple conditions and multiple materials. Therefore we recommend a plausibility check of the measuring results. Each device includes a serial number and the guarantee stamp. If those are broken, no claims for guarantee can be made. In case of a faulty device, please contact Schaller GmbH ([www.humimeter.com](http://www.humimeter.com)) or our dealer.

## Technical data BL2 wood chips probe (art. no. 12518)

<b>Resolution of display</b>	0.5% water content 0.5 °C temperature
<b>Measuring range</b>	10% to 50% water content
<b>Operation temperature</b>	0 °C to +40 °C
<b>Temperature measuring range</b>	-10 °C to +80 °C
<b>Dimension</b>	1150 x 35 x 35 mm
<b>Weight</b>	710 g
<b>Protection class</b>	IP 40



## Technical data BL2 hammer (art. no. 12520)

<b>Resolution of display</b>	0.1% water content 0.5 °C temperature
<b>Measuring range</b>	8% to 60% water content
<b>Operation temperature</b>	0 °C to +50 °C
<b>Temperature measuring range</b>	-10 °C to +60 °C
<b>Dimension</b>	360 x 45 x 45 mm
<b>Weight</b>	1500 g
<b>Protection class</b>	IP 40
<b>Option</b>	Replacement tips 60mm insulated, measuring tips set 255mm for bales of hay- and straw (art. no. 12521)



## Measuring tips set 255mm for bales of hay- and straw



### Most common reasons for miss readings with BL2 hammer

- ***Product temperature out of application range***  
Material below 0°C resp. above +50°C (32 to 122 °F) may cause faulty measurements.
- ***Temperature difference between meter and sample***  
Please ensure that the device and the material under test are being stored at the same temperature (+/-3°C) before measuring. A high temperature difference has a negative effect on the stability of the measurement results.
- ***Wrong calibration curve***  
Before you measure your sample, double check the correct selection of the calibration curve.
- ***Frozen wood or beetle infested wood***  
If you measure such products, the accuracy will decrease.
- ***Measurement through bark***  
In fact of that the accuracy will decrease.
- ***Direct solar radiation***



## Most common reasons for miss readings with BL2 wood chips probe

- **Product temperature out of application range**  
Material below 0°C resp. above +40°C (32 to 104 °F) may cause faulty measurements.
- **Temperature difference between meter and sample**  
Please ensure that the device and the material under test are being stored at the same temperature (+/-3°C) before measuring. A high temperature difference has a negative effect on the stability of the measurement results.
- **Wrong calibration curve**  
Before you measure your sample, double check the correct selection of the calibration curve.
- **Wet or mouldy material**
- **Frozen wood chips**  
If you measure such products, the accuracy will decrease.
- **Water film at the measuring head**  
After measuring wet material a water film can arise on the sensor head. This could lead to a too high result in the following measurement. After measuring wet material clean both black plastic parts accurately with a dry cloth.

**It is not allowed to load the measuring head incorrect** (stress, bending), otherwise it can be broken. Plug and remove the insertion probe of your BL2 wood chips probe straight into the wood chips.

Do not move the BL2 probe crosswise to the insertion direction after plugging in.

Do not drop the measuring head or use it for any ulterior purposes.

**A broken measuring head is no case of warranty!**

